


# SHAD

## PIAGGIO MEDLEY 125 '16 KIT TOP VOMD16ST



1 261976 x1



2 260523 x3  
Ø16 Ø9 x 25




3 303052 x3  
Ø6



4 302021 x3  
Ø6



5 303017 x2  
Ø6



6 304178 x2  
M6 x 60 DIN 912



7 304152 x1  
M6 x 50 DIN 7991

### ! WARNING!

GB

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

E

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

D

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

I

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

F

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

