10Upad for HJC IS-MAX2
Quick Start Guide

Right Speaker
Connection Cable

Center Button H
(+) Button (+)
(-) Button (-)
Status LED
(+) Button
Microphone
Left Speaker
Connection Cable

Installation

Charging

- Red: Charging
- Blue: Fully charged

Button Operation

Tap	Tapping	
1"	Press for 1 sec	
Tap Tap	Double Tapping	
5" 12"	Press and Hold	

Power On/Off

(+) + H ← 1" Press

Volume Adjustment

(+) or (-) ← Tap

Battery Check

Power On

LED

70 ~ 100%	▪-▪-▪ ▪ ▪ ▪ -···
30 ~ 70%	▪-▪-▪ ▪ ▪ -···
0 ~ 30%	▪-▪-▪ ▪ -···

Phone, Music Pairing

H ← 10" Press → (+) ← Tap

Select **Sena 10Upad**

LED ▪▪▪▪

Bluetooth
Device A
Sena 10Upad v2.0 ✓
Device B
......

Enter 0 0 0 0 PIN

Music Operation

▶ / ⏸	H ← 1" Press
⏪	(-) ← 1" Press
⏩	(+) ← 1" Press

Mobile Phone Call Making and Answering

📞 Answer	H	← Tap
📵 End	H	← 2" Press
🎤 Voice Dial	H	← 3" Press
⭐ Speed Dial	(+)	← 3" Press
📵 Reject	H	← 2" Press

Intercom | Pairing

Pairing
Headset A ← - - - - - - - → Headset B

[H] ← [5"]
Press
LED ■■■■

[H] ← [5"]
Press
LED ■■■■

[H] ← [Tap]

Intercom | Start/End

[H] ← [Tap]
1st Friend

[H] ← ← [Tap]
Double Tap
2nd Friend

[H] ← ← ← [Tap]
Triple Tap
3rd Friend

Radio | On/Off

[−] ← [1"]
Press

Radio | Seek Stations

[+] or [−] ← ← [Tap]
Double Tap

Radio | Scan Up FM Band

((•)) Start
or
Stop

[+] ← [1"]
Press

Save to preset while scanning

[Save] [H] ← [Tap]

Radio | Move to Preset Station

[H] ← [1"] |1|→|2|→····|5|····→|9|→|10|
Press

Radio | Save or Delete Preset

[H] ← [3"]
Press

1 ~ 10, Cancel [+] or [−] ← [Tap]

[Save] [+] ← [1"]
Press

or

[Delete] [−] ← [1"]
Press

Setting

Configuration Menu

[⚙] [H] ← [10"]
Press

Using the Sena Device Manager

Connect the headset to your computer via a USB cable. Launch the Sena Device Manager and click **DEVICE SETTING** to configure the headset settings.
For details about downloading the Sena Device Manager, please refer to the leaflet included in the package.

Using the Sena Smartphone App

1. On your smartphone, download the Sena Smartphone App for Android or iPhone from Google Play or App Store. Please refer to www.sena.com for more details.

2. Pair your smartphone with the headset.

3. Run the Sena Smartphone App. Swipe the screen to the right and tap Setting to configure the headset settings.

Troubleshooting

Factory Reset

If you want to restore the 10Upad to factory default settings, use the Factory Reset in the configuration menu. The headset automatically restores the default settings and turns off.

Fault Reset

If the 10Upad is not working properly for any reason, reset by gently pushing the pin-hole reset button located next to the DC Power Charging & Firmware Upgrade Port.

You can download the full version of the manual and view other Sena products at the Sena website: www.sena.com.

SENA

Sena Technologies, Inc.
www.sena.com
Customer Support: support.sena.com